

RD AUTO SPRAYER MANUAL

2020.06 ShenZhen
V3.02

INDEX

1	EQUIPMENT DESCRIPTION.....	1
1.1	USAGE	1
1.2	PARAMETERS	1
2	Knowledge the machine	2
3	Installation	3
4	Program gluing.....	7
4.1	Main menu	7
4.2	System setting menu	8
4.3	Dotty threadlike mixed programing	14
4.4	24 Volts control mode	15
4.5	Example programing	17
5	FAQ.....	18
5.1	Sprayer gun cannot spray manually	18
5.2	the gun work on manual spray but not on auto mode	18
5.3	Pump is not pumping glue	19
5.4	pump is pumping but not pump out the glue	19
5.5	Touchscreen is not working properly	19
6	Maintenance.....	20
6.1	Daily maintenance.....	20
6.2	Periodic maintenance.....	20

1 EQUIPMENT DESCRIPTION


1.1 USAGE

1.1.1 This machine is made by Advanced Algorithm Intelligent Electronic Pty Ltd. It is used for glue spraying on assembly line. It drives cold glue and hot glue by thread, dot or mix mode. It also drives double side taping machines. It has four main parts: controller, pump, spraying gun and encoder.

1.2 PARAMETERS



CONTROLLER	MODEL No.	RD-KZQ-4~64
	INPUT POWER	220VAC(±20%) 50-60Hz
	POWER RATE	500W
	ACCURACY	±0.1mm
	Dot Max Speed	180m/min
	Thread Max Speed	300m/min
	Product Max Length	No limit
	Samples storable	1000
	Guns controllable	4~64
	Sections programmable	11
PUMP	Model No.	RD-ZDB-2
	Stroke displacement	200cm ³
	Max glue viscosity	4000mPas
	Compression rate	5:1
	Inlet air requirments	2-8 bar
SPRAYER GUN	Model No.	RD-QA-02
	Nnozzle hole diameter	0.4mm/0.45mm
	Piston material	Silicon Oxide
	Operation mode	Magnetic injectjion
	Ooperating cycle	0.02 ms
	Injection adjustable	10 levels
	Glue adjusting knob	Yes
	Piston lifespan	5,000,000,000cycles
	Coating	Powder coating
	Detector	Panasonic infrared detector
	Fixture	protector
Detector protection	stainless steel case	
ENCODER	Manufacturer	OMRONG
	Wheel diameter	66.72mm
	wires	6

2 Knowledge the machine





3 Installation

1) Install encoder


Correct Way	Wrong way
	
<p>Install encoder to the belt which is used to run the product. The wheel touches the belt and bend the belt gently.</p>	<p>Do not place encoder wheel to belt wheel, otherwise gluing positioning will be affected, and encoder's lifespan could be reduced.</p>

2) Adjusting knob


High end	Low end
	
<p>Clockwise turning knob to lower the knob; Anti-clockwise turning knob to lift the knob. Take the following steps to adjust spraying gun:</p> <ol style="list-style-type: none"> 1. Clockwise turn the knob to the lower end; 2. Anti-clockwise turn the knob by 2 scales 3. Start manual spraying mode and see if spraying smoothly. If not switch off manual mode and anti-clockwise turn the knob by another 1 scale. Repeat above procedure until spraying smoothly. (please note: the maximum spraying is not the high end but in the middle point) 4. if need to adjust the size of spraying point, change “clean gun” to “test gun” on the touch screen's setting menu. 	

Spray glue to your product and see if result is satisfied. If not repeat step 1,2,3 to adjust.

3) Sprayer nozzle



Nozzle assembly order	Nozzle cut way view
	
<p>Please note: before remove the nozzle assembly, anti-clockwise the adjusting knob to the high end. When placing the nozzle back, do not use spanner. If feeling hard to turn the nozzle back, please double check if adjusting knob is on the high-end position.</p>	

4) Pump

Glue pressure adjustment	Pump Front view
	
<p>Red light stays on. Blue lights located above and below the red light, toggles each other. Another top right corner blue</p>	

light flicks every 1s. Normally, adjust the inlet air pressure to 6kg/cm³.

5) Product feed-in direction, gap between nozzle and product

Product feed in direction	Gap between nozzle and product
	

Above picture shows that products visit detector before meet spraying nozzle. The gap between nozzle and products recommends 5-10mm.


6) FILTER MAINTENANCE

PUMP FILTER	GLUE CONTAINER FILTER
	

Clean once per month with teeth brush and flush with clean tap water. Not cleaning properly might cause the nozzle blockage.


- 7) Connect air source and adjust the inlet air pressure to 6kg/cm³, then set up speed pressure curve.
- 8) Install sprayer gun, position the sprayer nozzle to where need to glue, and keep the gap between nozzle and product surface within 5-10mm.
- 9) When install encoder, make sure the wheel touches the belt closely. No specific direction required.
- 10) Connect joiner of spray gun, detector, pump and encoder.
- 11) Plug in 220v power cords.
- 12) Program the gluing.
- 13) Test.
- 14) Adjust and test.
- 15) Manufacturing
- 16) Please place nozzle sleeves with water back to nozzle after finish work. To void blockage we recommend throughout flush clean if not using the machine over 7 days.
- 17) Switch off power and air source.

4 Program gluing
4.1 Main menu




No.	Description
1	Manual switch, red means on, yellow means off
2	Auto switch, red means on, yellow means off
3	Channel setting button, blue indicates the channel we are setting.
4	Current channel no.
5	Setting Tab handler
6	Switch to toggle between manual dotting and threadlike
7	24 voltage switch
8	Open and save file
9	Channel group switch
10	Reserve button
11	Language Selection
12	Code version
13	Eye selection
14	Point size selection
15	Glue programming button groups, please note: 1. Distance from nozzle to eye, minimum is 10, maximum is 5 times of total product length. 2. The distance from nozzle to eye, can be used to move the whole gluing forward or backward
16	Gluing display, red is current editing section
17	Finished work piece, system will keep the total manufacturing quantity (refresh rate: once per second).
18	Encoder speed(refresh rate: once per second).
19	Pump pressure display for current group(refresh rate: once per second).

4.2 System setting menu
 a) Basic information display



No.	Description(refresh rate: once per second)
1	Display quantity of finished work piece for every channel, it will be reset after switched off
2	Indicate detector signal: grey is undetected, red is detected
3	Indicate manual signal: grey is 0, red is 1.
4	Encoder speed display

b) Pump control




No.	Description(refresh rate: five times per second)
1	Reconnect button is to reboot the pump and refresh the pump information
2	Pump status display

3	Temporary pressure setting: it is designed for testing. this setting is only valid when the speed is constant.
---	--

c) Pump pressure speed follower

Advanced settings: click System tab and input code:123456 to enter advance setting menu. System board use these parameters to adjust pump pressure according to encoder speed change. This helps sprayer output position-stable and quantity-stable gluing.




No.	Description	
1	Set parameters	
	Function	Function description
	Normal pressure	normal pressure given speed 0 to adjusting-edge speed
	Dotty spray max pressure	Maximum pressure point, above picture shows how pressure proportionally change according to speed.
	Critical pressure point	The value that system change from dotty spray mode into threadlike spray mode compulsorily
	Max pressure at threadlike mode	Max pressure at threadlike spray mode
	Start changing speed	The value is speed after which pump starts change pressure
	Critical speed point	This is the speed after which system use threadlike mode compulsorily
2	Max adjusting speed	Pump does not increase pressure after this speed
	Display area	
		Description
	X-axis	Encoder speed, unit: m/min
Y-axis	Glue pressure, unit: kg/cm³	

At top	The area under dotted line is normal speed mode at which sprayer can do point and threadlike spraying simultaneously; The area under solid line is high speed mode at which sprayer only do threadlike spraying.
Middle area	Pressure follower curve

d) Point spraying drive settings

This is an advance settings: Click Drive tab and enter code (this functions is for expert only, if you want to access this function, please ask our service engineer). This function set spray-point size, driving scaling as per speed change and intelligent control parameters.




No.	Description																						
1	Data setting area																						
	<table border="1"> <thead> <tr> <th>Function</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Max 100%</td> <td>The parameter with which system use to drive 100% glue point size at maximum output. Amplitude is 100.</td> </tr> <tr> <td>Max 10%</td> <td>The parameter with which system use to drive 10% glue point size at maximum output. Amplitude is 100.</td> </tr> <tr> <td>Min 100%</td> <td>The parameter with which system use to drive 100% glue point size at minimum output. Amplitude is 1.</td> </tr> <tr> <td>Min 10%</td> <td>The parameter with which system use to drive 10% glue point size at minimum output. Amplitude is 1.</td> </tr> <tr> <td>Start speed</td> <td>If the encoder speed is high than this, system uses speed as parameter to tune the spray drive.</td> </tr> <tr> <td>Start size</td> <td>The amplitude at the beginning of adjustment.</td> </tr> <tr> <td>Top speed</td> <td>Quicker than the speed, the amplitude keeps the same.</td> </tr> <tr> <td>Top Size</td> <td>The top limit of amplitude</td> </tr> <tr> <td colspan="2">The formula to calculate amplitude: $A = A_s - (V - V_s) / ((V_e - V_s) / (A_s - A_e))$</td> </tr> <tr> <td colspan="2">The formula to calculate the 100% point size :</td> </tr> </tbody> </table>	Function	Description	Max 100%	The parameter with which system use to drive 100% glue point size at maximum output. Amplitude is 100.	Max 10%	The parameter with which system use to drive 10% glue point size at maximum output. Amplitude is 100.	Min 100%	The parameter with which system use to drive 100% glue point size at minimum output. Amplitude is 1.	Min 10%	The parameter with which system use to drive 10% glue point size at minimum output. Amplitude is 1.	Start speed	If the encoder speed is high than this, system uses speed as parameter to tune the spray drive.	Start size	The amplitude at the beginning of adjustment.	Top speed	Quicker than the speed, the amplitude keeps the same.	Top Size	The top limit of amplitude	The formula to calculate amplitude: $A = A_s - (V - V_s) / ((V_e - V_s) / (A_s - A_e))$		The formula to calculate the 100% point size :	
Function	Description																						
Max 100%	The parameter with which system use to drive 100% glue point size at maximum output. Amplitude is 100.																						
Max 10%	The parameter with which system use to drive 10% glue point size at maximum output. Amplitude is 100.																						
Min 100%	The parameter with which system use to drive 100% glue point size at minimum output. Amplitude is 1.																						
Min 10%	The parameter with which system use to drive 10% glue point size at minimum output. Amplitude is 1.																						
Start speed	If the encoder speed is high than this, system uses speed as parameter to tune the spray drive.																						
Start size	The amplitude at the beginning of adjustment.																						
Top speed	Quicker than the speed, the amplitude keeps the same.																						
Top Size	The top limit of amplitude																						
The formula to calculate amplitude: $A = A_s - (V - V_s) / ((V_e - V_s) / (A_s - A_e))$																							
The formula to calculate the 100% point size :																							

	$S100 = (\text{Max}100 - \text{Min}100) * A / 100 + \text{Min}100$ <p>The formula to calculate the 10% point size :</p> $S10 = (\text{Max}10 - \text{Min}10) * A / 100 + \text{Min}10$ <p>The formula to calculate other point size :</p> $S = (S100 - S10) * (D_s - 1) / 9 + S10$																												
	<p>Symbols:</p> <table border="1"> <tr> <td>A</td> <td>Current amplitude</td> <td>S</td> <td>Point size</td> </tr> <tr> <td>As</td> <td>Starting amplitude</td> <td>S100</td> <td>100% point size</td> </tr> <tr> <td>Ae</td> <td>Top amplitude</td> <td>S10</td> <td>10% point size</td> </tr> <tr> <td>V</td> <td>Current speed</td> <td></td> <td></td> </tr> <tr> <td>Vs</td> <td>Starting speed</td> <td></td> <td></td> </tr> <tr> <td>Ve</td> <td>Top speed</td> <td></td> <td></td> </tr> <tr> <td>Ds</td> <td>Current ratio*10</td> <td></td> <td></td> </tr> </table>	A	Current amplitude	S	Point size	As	Starting amplitude	S100	100% point size	Ae	Top amplitude	S10	10% point size	V	Current speed			Vs	Starting speed			Ve	Top speed			Ds	Current ratio*10		
A	Current amplitude	S	Point size																										
As	Starting amplitude	S100	100% point size																										
Ae	Top amplitude	S10	10% point size																										
V	Current speed																												
Vs	Starting speed																												
Ve	Top speed																												
Ds	Current ratio*10																												
2	<p>Display area</p> <table border="1"> <tr> <td></td> <td>Description</td> </tr> <tr> <td>X-AXIS</td> <td>Encoder speed, unit: m/min</td> </tr> <tr> <td>Y-AXIS</td> <td>Spray drive amplitude</td> </tr> <tr> <td>MIDDLE AREA</td> <td>Spraying drive curve</td> </tr> </table>		Description	X-AXIS	Encoder speed, unit: m/min	Y-AXIS	Spray drive amplitude	MIDDLE AREA	Spraying drive curve																				
	Description																												
X-AXIS	Encoder speed, unit: m/min																												
Y-AXIS	Spray drive amplitude																												
MIDDLE AREA	Spraying drive curve																												
3	24-volts drive use the same way as cold gluing																												

e) Glue starting point compensate


This is an advance settings: Click System tab and enter code (this functions is for expert only, if you want to access this function, please ask our service engineer). This function set spray-point point size at the first few points larger than rest point at some scale.



No.	Description																										
1	Data set area																										
	Name	Description																									
	Max compensation	Starting points Max compensation, amplitude is 100																									
	Min compensation	Starting points min compensation, amplitude is 10																									
	Start speed	The speed at which compensation function start to intervene																									
	Start amplitude	The amplitude at start speed																									
	Turning point speed	The speed at which slope changes																									
	Turning point amplitude	The amplitude at turning point speed																									
	Top speed	The top speed compensation function would work for																									
	Top amplitude	The amplitude at the top speed																									
	Dot Num	The point number you want to compensate																									
	Max Amp	The fixed amplitude after top speed																									
	To calculate the amplitude at given speed: $A = (V - V1) / ((Vn - V1) / (An - A1))$ The real compensation: $R = (Rmax - Rmin) * A / 100 + Rmin$																										
	<table border="1"> <thead> <tr> <th colspan="4">Symbols</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>The current compensation amplitude</td> <td>R</td> <td>Real compensation value</td> </tr> <tr> <td>A1</td> <td>The last amplitude</td> <td>Rmax</td> <td>Max compensation</td> </tr> <tr> <td>An</td> <td>The next amplitude</td> <td>Rmin</td> <td>Min compensation</td> </tr> <tr> <td>V</td> <td>The current speed</td> <td></td> <td></td> </tr> <tr> <td>V1</td> <td>The last setting speed</td> <td>Vn</td> <td>The next setting speed</td> </tr> </tbody> </table>				Symbols				A	The current compensation amplitude	R	Real compensation value	A1	The last amplitude	Rmax	Max compensation	An	The next amplitude	Rmin	Min compensation	V	The current speed			V1	The last setting speed	Vn
Symbols																											
A	The current compensation amplitude	R	Real compensation value																								
A1	The last amplitude	Rmax	Max compensation																								
An	The next amplitude	Rmin	Min compensation																								
V	The current speed																										
V1	The last setting speed	Vn	The next setting speed																								
2	Display area																										
		Description																									
	X-axis	Encoder speed, unit: m/min																									
	Y-axis	Compensation amplitude																									
	Middle area	Compensation curve																									
3	24 volts setting use the same way as above																										

f) Other settings:

This is an advance settings: Click System tab and enter code (123456).




NO.	Description																																									
1	Minimum detected length, unit: mm. This value is used to reduce the interference. Signal is not valid until the detected length is longer than this value. This value is not valid if it is bigger than the distance from nozzle to detector.																																									
2	Restore to factory default settings <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Functions</th> <th>If restore</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Sprayer auto & manual switch</td> <td>Yes</td> </tr> <tr> <td>2</td> <td>Manual spray status</td> <td>Yes</td> </tr> <tr> <td>3</td> <td>24 volts mode</td> <td>Yes</td> </tr> <tr> <td>4</td> <td>Encoder Selection</td> <td>Yes</td> </tr> <tr> <td>5</td> <td>Eye Selection</td> <td>Yes</td> </tr> <tr> <td>6</td> <td>Glue point size</td> <td>Yes</td> </tr> <tr> <td>7</td> <td>Glue programming</td> <td>Yes</td> </tr> <tr> <td>8</td> <td>Pressure follower</td> <td>Yes</td> </tr> <tr> <td>9</td> <td>Dot spray drive</td> <td>Yes</td> </tr> <tr> <td>10</td> <td>Start point compensation mode</td> <td>Yes</td> </tr> <tr> <td>11</td> <td>Minimum detected distance</td> <td>Yes</td> </tr> <tr> <td>12</td> <td>Number of worked piece</td> <td>No</td> </tr> <tr> <td>13</td> <td>Saved file</td> <td>No</td> </tr> </tbody> </table>	Functions	If restore	1	Sprayer auto & manual switch	Yes	2	Manual spray status	Yes	3	24 volts mode	Yes	4	Encoder Selection	Yes	5	Eye Selection	Yes	6	Glue point size	Yes	7	Glue programming	Yes	8	Pressure follower	Yes	9	Dot spray drive	Yes	10	Start point compensation mode	Yes	11	Minimum detected distance	Yes	12	Number of worked piece	No	13	Saved file	No
Functions	If restore																																									
1	Sprayer auto & manual switch	Yes																																								
2	Manual spray status	Yes																																								
3	24 volts mode	Yes																																								
4	Encoder Selection	Yes																																								
5	Eye Selection	Yes																																								
6	Glue point size	Yes																																								
7	Glue programming	Yes																																								
8	Pressure follower	Yes																																								
9	Dot spray drive	Yes																																								
10	Start point compensation mode	Yes																																								
11	Minimum detected distance	Yes																																								
12	Number of worked piece	No																																								
13	Saved file	No																																								


4.3 Dotty threadlike mixed programing

The button named If Injecting Line is used to toggle between dot and threadlike. Every section can be configured.

Dotty spray programming




Threadlike spray programming




4.4 24 Volts control mode


Normal mode is like this:




Click the button named 24v unused, you will see the following window:



Please read carefully, then click I accept, system enter 24v mode:




As above picture, the button name has changed into “24v used”. And new button named “hot glue mode” shows up. Click hot glue mode button, you can select sub-24v working mode.



Please note although 24v mode can drive hot glue gun, double-side taper etc, we cannot connect the cold glue spray gun by using 24v mode.

4.5 Example programming



Total product length: 210mm; the first section start point:10mm; points gap is 5mm, end point is 75, dotted spray; the second section use threadlike spray; starts from 100mm, end at 150mm. Now we begin to edit program:

- 1 Do the measurements: along with product moving direction, measure from the edge of product to the end edge of product.
- 2 Enter into the glue pattern editing menu.
- 3 Click to delete all of the current data.
- 4 Check if current section is “section 1”, if not click to change to “section 1”
- 5 Click and input the total paper length:210.
- 6 Input the gap between spray gun and detector, here we use default value: 45mm.
- 7 Click the button “if do lin” to turn it into grey color, button text should show “Do dot” .
- 8 Input glue gap as 5mm.
- 9 Input start point as 10mm.
- 10 Input end point as 75mm.
- 11 Number of points shows:14
- 12 Click button “next part” and change to “part 2”
- 13 Click “if do line” button and button color goes to red(point gap, number of points will be hidden.
- 14 Input start point:100
- 15 Input end point:150
- 16 Gluing programming finished. Now you can save the program or go back to settings menu.
- 17 Go back to main menu and click run auto to test spraying result

5 FAQ

5.1 Sprayer gun cannot spray manually

Reason 1: sprayer gun connector is not plugged in properly.

Solution: unplug and plug

Reason 2: 4 channel valve is not open.

Solution: turn on the valve

Reason 3: auto-run is switched on.

Solution: switch off auto-run.

Reason 4: blockage

Solution: flush clean the nozzle or even the pump and pipe; if still happening, change the glue.

Reason 5: nozzle, piston and spring is not well positioned.

Solution: reassemble them properly.

Reason 6: spray gun malfunction.

Solution: call us and get it repaired or replaced.

5.2 the gun work on manual spray but not on auto mode

Reason 1: no speed is detected.

Solution: if encoder wheel is not touching the belt, adjust it; if still the same problem, change the encoder.

Reason 2: detector is not working properly.

Solution: if indicator of detector is not on, plug the detector to another channel, if still the same problem, send it back manufacturer. If green indicator is on, and yellow indicator is not on while paper goes under it, use flat screw driver to turn the knob to far direction. If green indicator is on and yellow one is also on all the time, we need reposition the detector.

Reason 3: auto-run is not switched on or programming has some error.

Solution: make sure auto-run is on and reprogram the gluing.

5.3 Pump is not pumping glue

Reason 1: no air source connected or inlet air pressure is under the limit.

Solution: connect the air source or correct air supply pressure properly.

Reason 2: inlet air pressure control valve is not adjust properly.

Solution: turn the valve knob and adjust the inlet pressure to $6\text{kg}/\text{cm}^2$.

5.4 pump is pumping but not pump out the glue

Reason 1: container has no glue left.

Solution: add glue.

Reason 2: there is air in the glue channel.

Solution: switch off 4 channel valves, remove one of spray gun pipe from the valve, then gently switch on the valve to “squeeze” out the air.

Reason 3: the one-way ceramic ball is stuck.

Solution: remove glue pipe from container, and use long flat screw driver to push the ceramic ball to make it moving.

Install the glue pipe back.

5.5 Touchscreen is not working properly

Reason 1: electro-interference affect the system communication

Solution: use wire connect controller case to ground wire

Reason 2: controller malfunction.

Solution: call us to get it repaired

6 Maintenance

6.1 Daily maintenance

- i No other spare part or device placed on the equipment.
- ii Keep the equipment clean and make sure no glue is visible on equipment surface.
- iii Check pressure gauge because over pressure will cause gauge or other parts damage.
- iv Check the water level of inlet air pressure control valve water container. If level is over 1/3, please release the water.
- v Put nozzle protection sleeves back to nozzle if not using the sprayer gun.
- vi Clean the nozzle before using.
- vii Avoid step on the pipe and wire of the equipment.
- viii Clean the glue container if long-time no usage.
- ix Flush clean the glue channel if over 7 days no using the equipment.
- x Flush clean the glue channel before using different brand or model of glue. **Do not mix up 2 different type of glue together.**
- xi Switch off the 4 channel valves before cleaning the nozzle. **The O-ring on the nozzle need to be check before placing the nozzle back. Defected O-ring might cause serious glue leaking.**
- xii Check the encoder wheel and see if it touches belt.

6.2 Periodic maintenance

Add 100ml lubricant every 6 month. You can use motor oil.

Pump filter need to be clean every 3 months. We recommend you use special tool supplied with machine as accessory to open up the filter container. Flush clean the spray gun every 3 months.

Filter under the container need to be clean every 3 months.